

Step by step

Installation Guide



Clean your subfloor before starting – ensure that the subfloor is even, dry, clean and pressure-resistant.



ProVent should be rolled onto the floor with the vapour barrier upwards, parallel to the wall and at right angles to the direction in which you plan to lay the floor covering.



Begin the installation of the floor on the first row of underlay. Follow the manufacturer's instructions.



Unroll the next row of underlay. Overlap the rows. If installing over cement screed, the joints should be sealed with a waterproof tape such as duck tape.

Continue to install your flooring over the underlay. Repeat the previous steps until your floor is completed.